

ecutek

ProECU Mitsubishi Colt CZT



DTC List

2005-onward Model Year CAN ECUs

v1.1

P0090	Fuel pressure control solenoid valve system
P0100	Air flow sensor system
P0105	Manifold absolute pressure sensor system
P0110	Intake air temperature sensor system
P0115	Engine coolant temperature sensor system
P0122	Throttle position sensor (main) circuit low input
P0123	Throttle position sensor (main) circuit high input
P0125	Feedback system monitor
P0130	Oxygen sensor (front) system
P0135	Oxygen sensor (front) heater system
P0136	Oxygen sensor (rear) system
P0141	Oxygen sensor (rear) heater system
P0170	Abnormal fuel system
P0201	No.1 injector system
P0202	No.2 injector system
P0203	No.3 injector system
P0222	Throttle position sensor (sub) circuit low input
P0223	Throttle position sensor (sub) circuit high input
P0243	Waste gate solenoid valve system
P0300	Random/multiple cylinder misfire detected
P0300	Random/multiple cylinder misfire detected
P0301	No. 1 cylinder misfire detected
P0302	No. 2 cylinder misfire detected
P0303	No. 3 cylinder misfire detected
P0304	No. 4 cylinder misfire detected
P0325	Detonation sensor system
P0335	Crank angle sensor system
P0340	Camshaft position sensor system
P0420	Catalyst malfunction
P0443	Purge control solenoid valve system
P0500	Vehicle speed signal system
P0513	Immobilizer malfunction
P0603	ECU ROM
P0606	Engine-ECU main processor malfunction
P0622	Alternator FR terminal system
P0638	Throttle valve control servo circuit range/performance problem
P0657	Throttle valve control servo relay circuit malfunction
P0657	Throttle valve control servo relay circuit malfunction
P1021	Oil control valve system
P1021	Oil control valve system
P1603	Battery backup circuit malfunction
P1603	Battery backup circuit malfunction
P1630	Variant coding errors
P1630	Variant coding errors
P1961	Trustful check throttle position sensor (main)
P1962	Trustful check throttle position sensor (sub)
P1963	Trustful check manifold absolute pressure sensor
P1964	AD converter
P1965	Trustful check accelerator pedal position sensor
P1966	Manifold absolute pressure sensor trustful for torque monitoring
P1967	Trustful check engine speed
P1970	Torque monitoring
P1971	Fail-safe control monitoring
P1978	Throttle valve control servo malfunction

P2100 Throttle valve control servo circuit (open)
P2122 Accelerator pedal position sensor (main) circuit low input
P2123 Accelerator pedal position sensor (main) circuit high input
P2127 Accelerator pedal position sensor (sub) circuit low input
P2128 Accelerator pedal position sensor (sub) circuit high input
P2135 Throttle position sensor (main and sub) range/performance problem
P2138 Accelerator pedal position sensor (main and sub) range/performance problem
U1108 Combination meter time-out